


Translator

VGA To DVI Converter/Scaler

ROSE.COM

INSTALLATION AND OPERATIONS MANUAL



LIMITED WARRANTY

Rose Electronics® warrants the Rose Translator to be in good working order for one year from the date of purchase from Rose Electronics or an authorized dealer. Should this product fail to be in good working order at any time during this one-year warranty period, Rose Electronics will, at its option, repair or replace the Unit as set forth below. Repair parts and replacement units will be either reconditioned or new. All replaced parts become the property of Rose Electronics. This limited warranty does not include service to repair damage to the Unit resulting from accident, disaster, abuse, or unauthorized modification of the Unit, including static discharge and power surges.

Limited Warranty service may be obtained by delivering this unit during the one-year warranty period to Rose Electronics or an authorized repair center providing a proof of purchase date. If this Unit is delivered by mail, you agree to insure the Unit or assume the risk of loss or damage in transit, to prepay shipping charges to the warranty service location, and to use the original shipping container or its equivalent. You must call for a return authorization number first. Under no circumstances will a unit be accepted without a return authorization number. Contact an authorized repair center or Rose Electronics for further information.

ALL EXPRESS AND IMPLIED WARRANTIES FOR THIS PRODUCT INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO A PERIOD OF ONE YEAR FROM THE DATE OF PURCHASE, AND NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, WILL APPLY AFTER THIS PERIOD. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU.

IF THIS PRODUCT IS NOT IN GOOD WORKING ORDER AS WARRANTIED ABOVE, YOUR SOLE REMEDY SHALL BE REPLACEMENT OR REPAIR AS PROVIDED ABOVE. IN NO EVENT WILL ROSE ELECTRONICS BE LIABLE TO YOU FOR ANY DAMAGES INCLUDING ANY LOST PROFITS, LOST SAVINGS OR OTHER INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OF OR THE INABILITY TO USE SUCH PRODUCT, EVEN IF ROSE ELECTRONICS OR AN AUTHORIZED DEALER HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, OR FOR ANY CLAIM BY ANY OTHER PARTY.

SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR CONSUMER PRODUCTS, SO THE ABOVE MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH MAY VARY FROM STATE TO STATE.

NOTE: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Subpart J of Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

IBM, AT, and PS/2 are trademarks of International Business Machines Corp. Microsoft and Microsoft Windows are registered trademarks of Microsoft Corp. Any other trademarks mentioned in this manual are acknowledged to be the property of the trademark owner.

TABLE OF CONTENTS

Contents	Page #
Disclaimer	1
System Introduction	1
About this manual	1
Features	1
Package Contents	1
Rose Translator Models	2
Top View	2
Front View	2
Rear View	2
Installation	3
Rose Translator Operation	4
Rose Translator Menu System	4
Navigating the Menu System	5
Output Setup Menu Item	7
Output Resolution	7
Picture Menu Item	9
Contrast	9
Brightness	10
Saturation	11
Hue	12
Color Range	13
Color Temperature	14
Color Balance	15
Edge Enhance	16
Sharpness	17
Adjustment Menu Item	18
Under scan / Over scan	18
Aspect Ratio	19
Horizontal Mirror	20
Vertical Mirror	21
Horizontal Shift	22
Vertical Shift	23
Phase	24
System Menu Item	25
OSD Timeout	25
Display Notify	26
Input Resolution Information	27
Firmware Version	28
Factory Reset	29
Test Patterns Menu Item	30
Dip Switch Configuration	31
Safety	32
Maintenance and Repair	33
Technical Support	33

Figures

Page

Figure 1. Rose Translator Top View	2
Figure 2. Rose Translator Front View	2
Figure 3. Rose Translator Rear View	2
Figure 4. Rose Translator Installation	3
Figure 5. Menu Controls on the Rose Translator	4
Figure 6. Menu System Display	4
Figure 7. Main Menu and Submenus	5
Figure 8. System Menu Item and Submenu	5
Figure 9. Submenu Item Selection	5
Figure 10. Navigating the Submenu	5
Figure 11. Selected Submenu Item	6
Figure 12. Menu System is Redisplayed after Submenu Item Selection	6
Figure 13. Going Back to the Main Menu	6
Figure 14. Exiting the Menu System	6
Figure 15. Output Setup Menu	7
Figure 16. Output Resolution Selection Box	7
Figure 17. Current Resolution Display	7
Figure 18. Output Resolution Selection Box With Final Selection	7
Figure 19. Return to Output Setup Menu	8
Figure 20. Picture Submenu with Contrast Highlighted	9
Figure 21. Contrast Selection Box	9
Figure 22. Picture Submenu with Brightness Highlighted	10
Figure 23. Brightness Selection Box	10
Figure 24. Picture Submenu with Brightness Highlighted	11
Figure 25. Saturation Selection Box	11
Figure 26. Picture Submenu with Hue Highlighted	12
Figure 27. Hue Selection Box	12
Figure 28. Picture Submenu with Color Range Highlighted	13
Figure 29. Color Range Selection Box	13
Figure 30. Picture Submenu with Color Temp. Highlighted	14
Figure 31. Color Temp. Selection Box	14
Figure 32. Picture Submenu with Color Balance. Highlighted	15
Figure 33. Color Balance. Select Color Selection Box	15
Figure 34. Set Color Balance for Selected Color Selection Box	15
Figure 35. Picture Submenu with Edge Enhance. Highlighted	16
Figure 36. Edge Enhance Selection Box	16
Figure 37. Picture Submenu with Sharpness Highlighted	17
Figure 38. Sharpness Selection Box	17
Figure 39. Adjustment Submenu with Under/Over Scan Highlighted	18
Figure 40. Under/Over Scan Selection Box	18
Figure 41. Adjustment Submenu with Aspect Ratio Highlighted	19
Figure 42. Aspect Ratio Selection Box	19
Figure 43. Adjustment Submenu with H-Mirror Highlighted	20
Figure 44. Horizontal Mirror Selection Box	20
Figure 45. Horizontal Mirror for an Image	20
Figure 46. Adjustment Submenu with V-Mirror Highlighted	21
Figure 47. Vertical Mirror Selection Box	21
Figure 48. Vertical Mirror for an Image	21
Figure 49. Adjustment Submenu with H-Shift Highlighted	22
Figure 50. Horizontal Shift Selection Box	22
Figure 51. Adjustment Submenu with V-Shift Highlighted	23
Figure 52. Vertical Shift Selection Box	23
Figure 53. Adjustment Submenu with Phase Highlighted	24
Figure 54. Phase Selection Box	24
Figure 55. System Submenu with OSD Timeout Highlighted	25
Figure 56. OSD Timeout Selection Box	25
Figure 57. System Submenu with Display Notify Highlighted	26

Figure 58. Display Notify Selection Box.....	26
Figure 59. System Submenu with Input Res. Info Highlighted	27
Figure 60. Input Res. Info Display Box	27
Figure 61. System Submenu with F/W Version Highlighted.....	28
Figure 62. F/W Version Display Box.....	28
Figure 63. System Submenu with Factory Reset Highlighted	29
Figure 64. Factory Reset Selection Box	29
Figure 65. Test Patterns Submenu with White Highlighted.....	30
Figure 66. Available Test Patterns on the Video Converter and Scaler	30
Figure 67. Dip Switch on the Video Converter and .Scaler	31
Figure 68. Output Setup Submenu System	35
Figure 69. Picture Submenu System	36
Figure 70. Adjustment Submenu System	37
Figure 71. System Submenu System	38
Figure 72. Test Patterns Submenu System.....	39
Figure 73. Exit Submenu System.....	39
Figure 74. Mounting the Rose Translator	41

Tables	Page #
Table 1. Dip Switch Configuration	31
Table 2. Rose Translator Specifications	34
Table 3. Default Menu Settings	40

Appendices	Page #
Appendix A- Specifications.....	34
Appendix B- Menu System Summary	35
Output Setup Menu	35
Picture Menu	36
Adjustment Menu	37
System Menu	38
Test Patterns Menu	39
Exit Menu System	39
Appendix C – Default Settings.....	40
Appendix D- Surface Mounting Instructions.....	41

INTRODUCTION

Disclaimer

While every precaution has been taken in the preparation of this manual, the manufacturer assumes no responsibility for errors or omissions. Neither does the manufacturer assume any liability for damages resulting from the use of the information contained herein. The manufacturer reserves the right to change the specifications, functions, circuitry of the product, and manual content at any time without notice.

The manufacturer cannot accept liability for damages due to misuse of the product or other circumstances outside the manufacturer's control. The manufacturer will not be responsible for any loss, damage, or injury arising directly or indirectly from the use of this product. (See limited warranty.)

System Introduction

Thank you for choosing the Rose Translator (VGA to DVI Converter/Scaler). The Rose Translator is the result of Rose Electronics commitment to providing state-of-the-art solutions for today's demanding workplace. The unit allows locations with legacy computers to streamline their operations by converting the video to utilize newer higher-resolution monitors.

The Rose Translator is designed to connect analog graphic cards to DVI compliant digital monitors. Computers, laptops, or other VGA sources with HD15 video connectors can be connected to a DVI video display using the VGA to DVI Converter/Scaler. The video can be scaled up to 1080p Full HD and 1920 x 1200 (WUXGA). An intuitive and comprehensive on-screen display (OSD) menu allows easy set-up and control.

Wide power supply operating range of 6V to 24V DC offers installation flexibility for mobile use, in complex studio systems with a common power supply, and with remotely located power sources. A locking power supply connector, small footprint, and a surface-mountable enclosure facilitate easy and secure installation.

About this manual

This manual covers the installation and operation of the Rose Translator. The Installation Section describes how to connect the unit. The Operation section describes the OSD menus, and the functionality of the dip switch.

Features

- Converts and scales VGA to DVI
- Input resolutions up to 1920 x 1200 (WUXGA)
- Output resolutions up to 1080p60, 2048 x 1080, and 1920 x 1200 (WUXGA)
- On-screen display (OSD) menu allows easy set-up and control
- Aspect Ratio Control: Source, 16:9, 4:3 and Stretch
- Test Pattern Generator for quick system configuration
- Wide power supply operating range (6V to 24V DC)
- Locking power supply connector
- Surface mountable

Package Contents

The package contents consist of the following:

The Rose Translator Unit as ordered

1 x 6 ft. VGA cable (M-M)

1 x 12V Power Supply

Manual

Additional cables are usually ordered separately. If the package contents are not correct, contact Rose Electronics or your reseller so the problem can be quickly resolved.

Rose Translator Models

The Rose Translator comes in a single model as shown below.

Top View




Figure 1. Rose Translator Top View

Front View




Figure 2. Rose Translator Front View

Buttons / Connectors:

1. **DVI OUT:** Use a DVI cable to connect a DVI display to this port.
2. **▲, ▼, MENU:** These push buttons are used to change settings within the on-screen menu system. See the Rose Translator Menu System section on page 4 for more information.

Rear View




Figure 3. Rose Translator Rear View

Connectors / Indicators:

1. **VGA IN:** Connect included VGA cable from source device (e.g. computer) to this port
2. **USB:** This mini-USB port is reserved for use by Rose Electronics.
3. **12V DC:** Connect included 12V DC power supply to this power receptacle.
4. **PWR:** Under normal operating conditions, this LED indicator will glow bright blue.

INSTALLATION

Installation

Installation of the Rose Translator is very simple. The steps to do so are outlined below.

1. Connect the included VGA cable from the video source (e.g. a computer) to the *VGA IN* port on the unit.
2. Connect a DVI cable from the *DVI OUT* port to a DVI display.
3. Connect the included power supply to the *12V DC* power receptacle on the unit, and connect the power unit to an available electrical outlet.

The completed installation will appear as in the figure below.




Figure 4. Rose Translator Installation

Rose Translator Operation

This section deals primarily with the menu system of the Rose Translator and the functionality it provides. In addition, the function of the unit's dip switch is discussed here

Rose Translator Menu System

The Rose Translator uses a built-in menu system to manage and control all video features. To display the menu system, press the *MENU* button on the front panel.




Figure 5. Menu Controls on the Rose Translator

The menu system will be displayed in the upper-left corner of the screen, as shown in the figure below.



Figure 6. Menu System Display

If the menu system is not used within the time interval specified by the *OSD Timeout* setting, the menu system will be automatically closed. By default, the *OSD Timeout* setting is 5 seconds. See the *OSD Timeout* section on page 25 for instructions on setting the *OSD Timeout* value.

Navigating the Menu System

The main menu contains six menu items: *Output Setup*, *Picture*, *Adjustment*, *System*, *Test Patterns* and *Exit*. The currently selected menu item in the main menu will always be highlighted in yellow.

Each menu item within the main menu, with the exception of *Exit*, contains a submenu. The submenu for a menu item is displayed automatically when the menu item is selected.




Figure 7. Main Menu and Submenus

Use the ▲ or ▼ button on the front panel to highlight the desired item within the main menu. For example, if the ▼ button is pressed three times, the *System* menu item is highlighted, and its submenu displayed.




Figure 8. System Menu Item and Submenu

To access the submenu for the highlighted menu item in the main menu, press the *MENU* button a second time. When a submenu is activated, a green bar is used to indicate the current selection.




Figure 9. Submenu Item Selection

Use the ▲ or ▼ button to navigate through the submenu.



Figure 10. Navigating the Submenu

Select the highlighted submenu item by pressing the *MENU* button. For example, if the *MENU* button is pressed when the *Input Res. Info* submenu item is highlighted, the menu system is cleared from the screen, and the following will be displayed.



Figure 11. Selected Submenu Item

Press the *MENU* button to return to the menu system.




Figure 12. Menu System is Redisplayed after Submenu Item Selection

To exit the submenu and return to the main menu, use the ▲ or ▼ button to highlight the <- Back submenu item.




Figure 13. Going Back to the Main Menu

To exit the menu system, use the ▲ or ▼ button to highlight the *Exit* option and press the *MENU* button.



Figure 14. Exiting the Menu System

Output Setup Menu Item

The *Output Setup* menu item has just one item in its submenu. This is the *Output Resolu.* submenu item.

Output Resolution

⚠ Warning: Prior to changing this setting, ensure that the connected display can support the selected output resolution. **If an unsupported resolution is selected, the unit will need to be reset using the dip switch on the bottom of the unit.** See the Dip Switch Configuration section on page 31 for more information.

1. Press the *MENU* button on the front panel of the unit. The *Output Setup* menu item will be highlighted.




Figure 15. *Output Setup Menu*

2. Press the *MENU* button to access the *Output Setup* submenu. The *Output Resolu.* submenu item will be highlighted.
3. Press the *MENU* button to select the *Output Resolu.* submenu item.
4. The *Output Resolu.* selection box will be displayed.



Figure 16. *Output Resolution Selection Box*

5. Use the ▲ or ▼ button to select the desired resolution. For a list of available output resolutions that are supported by the Rose Translator, see Appendix B- Menu System Summary on page 35.
6. After the desired output resolution is selected, press the *MENU* button to confirm the change.
7. When the output resolution has changed, the current input and output resolutions will be displayed above the *Output Resolu.* selection box.




Figure 17. *Current Resolution Display*

i Note: The input / output resolution display will only be displayed if *Display Notify* is set to *On*. See the Display Notify section on page 26 for more information.

8. After a few seconds the Current Resolution Display will be removed.
9. The *Output Resolu.* selection box will still be displayed.



Figure 18. *Output Resolution Selection Box With Final Selection*

10. Press the *MENU button* to return to the *Output Setup* menu.




Figure 19. Return to Output Setup Menu

11. Use the ▲ or ▼ button to select the <- *Back* submenu item.
12. Press the *MENU button*.
13. Use the ▲ or ▼ button to select the *Exit* menu item.
14. Press the *MENU button* to exit the main menu.

Picture Menu Item

The *Picture* menu item provides several options to set the attributes of the displayed picture. These are described below.

Contrast

1. Press the *MENU* button on the front panel of the unit. The *Output Setup* menu item will be highlighted.
2. Use the ▲ or ▼ button to highlight the *Picture* menu item.
3. Press the *MENU* button to display the *Picture* submenu. The *Contrast* submenu item will be highlighted.




Figure 20. Picture Submenu with Contrast Highlighted

4. Press the *MENU* button to select the *Contrast* submenu item.
5. The *Contrast* selection box will be displayed.



Figure 21. Contrast Selection Box

6. Use the ▲ or ▼ button to set the desired contrast level.
7. Press the *MENU* button to confirm the change and return to the *Picture* submenu.
8. Use the ▲ or ▼ button to select the <- *Back* submenu item.
9. Press the *MENU* button.
10. Use the ▲ or ▼ button to select the *Exit* menu item.
11. Press the *MENU* button to exit the main menu.

Brightness

1. Press the *MENU button* on the front panel of the unit. The *Output Setup* menu item will be highlighted.
2. Use the ▲ or ▼ button to highlight the *Picture* menu item.
3. Press the *MENU button* to display the *Picture* submenu. The *Contrast* submenu item will be highlighted.
4. Use the ▲ or ▼ button to highlight the *Brightness* submenu item.




Figure 22. Picture Submenu with Brightness Highlighted

5. Press the *MENU button* to select the *Brightness* submenu item.
6. The *Brightness* selection box will be displayed.



Figure 23. Brightness Selection Box

7. Use the ▲ or ▼ button to set the desired brightness level.
8. Press the *MENU button* to confirm the change and return to the *Picture* submenu.
9. Use the ▲ or ▼ button to select the <- *Back* submenu item.
10. Press the *MENU button*.
11. Use the ▲ or ▼ button to select the *Exit* menu item.
12. Press the *MENU button* to exit the main menu.

Saturation

1. Press the *MENU button* on the front panel of the unit. The *Output Setup* menu item will be highlighted.
2. Use the ▲ or ▼ button to highlight the *Picture* menu item.
3. Press the *MENU button* to display the *Picture* submenu. The *Contrast* submenu item will be highlighted.
4. Use the ▲ or ▼ button to highlight the *Saturation* submenu item.




Figure 24. Picture Submenu with Brightness Highlighted

5. Press the *MENU button* to select the *Saturation* submenu item.
6. The *Saturation* selection box will be displayed.



Figure 25. Saturation Selection Box

7. Use the ▲ or ▼ button to set the desired saturation level.
8. Press the *MENU button* to confirm the change and return to the *Picture* submenu.
9. Use the ▲ or ▼ button to select the <- Back submenu item.
10. Press the *MENU button*.
11. Use the ▲ or ▼ button to select the *Exit* menu item.
12. Press the *MENU button* to exit the main menu.

Hue

1. Press the *MENU button* on the front panel of the unit. The *Output Setup* menu item will be highlighted.
2. Use the ▲ or ▼ button to highlight the *Picture* menu item.
3. Press the *MENU button* to display the *Picture* submenu. The *Contrast* submenu item will be highlighted.
4. Use the ▲ or ▼ button to highlight the *Hue* submenu item.




Figure 26. Picture Submenu with Hue Highlighted

5. Press the *MENU button* to select the *Hue* submenu item.
6. The *Hue* selection box will be displayed.



Figure 27. Hue Selection Box

7. Use the ▲ or ▼ button to set the desired hue.
8. Press the *MENU button* to confirm the change and return to the *Picture* submenu.
9. Use the ▲ or ▼ button to select the <- *Back* submenu item.
10. Press the *MENU button*.
11. Use the ▲ or ▼ button to select the *Exit* menu item.
12. Press the *MENU button* to exit the main menu.

Color Range

1. Press the *MENU button* on the front panel of the unit. The *Output Setup* menu item will be highlighted.
2. Use the ▲ or ▼ button to highlight the *Picture* menu item.
3. Press the *MENU button* to display the *Picture* submenu. The *Contrast* submenu item will be highlighted.
4. Use the ▲ or ▼ button to highlight the *Color Range* submenu item.




Figure 28. Picture Submenu with Color Range Highlighted

5. Press the *MENU button* to select the *Color Range* submenu item.
6. The *Color Range* selection box will be displayed.



Figure 29. Color Range Selection Box

7. Use the ▲ or ▼ button to select between *Limited* and *Full*.
8. Press the *MENU button* to confirm the change and return to the *Picture* submenu.
9. Use the ▲ or ▼ button to select the <- *Back* submenu item.
10. Press the *MENU button*.
11. Use the ▲ or ▼ button to select the *Exit* menu item.
12. Press the *MENU button* to exit the main menu.

Color Temperature

1. Press the *MENU button* on the front panel of the unit. The *Output Setup* menu item will be highlighted.
2. Use the ▲ or ▼ button to highlight the *Picture* menu item.
3. Press the *MENU button* to display the *Picture* submenu. The *Contrast* submenu item will be highlighted.
4. Use the ▲ or ▼ button to highlight the *Color Temp.* submenu item.




Figure 30. Picture Submenu with Color Temp. Highlighted

5. Press the *MENU button* to select the *Color Temp.* submenu item.
6. The *Color Temp.* selection box will be displayed.



Figure 31. Color Temp. Selection Box

7. Use the ▲ or ▼ button to select between *Neutral*, *Cool* and *Warm*.
8. Press the *MENU button* to confirm the change and return to the *Picture* submenu.
9. Use the ▲ or ▼ button to select the <- *Back* submenu item.
10. Press the *MENU button*.
11. Use the ▲ or ▼ button to select the *Exit* menu item.
12. Press the *MENU button* to exit the main menu.

Color Balance

1. Press the *MENU button* on the front panel of the unit. The *Output Setup* menu item will be highlighted.
2. Use the ▲ or ▼ button to highlight the *Picture* menu item.
3. Press the *MENU button* to display the *Picture* submenu. The *Contrast* submenu item will be highlighted.
4. Use the ▲ or ▼ button to highlight the *Color Balance* submenu item.




Figure 32. Picture Submenu with Color Balance Highlighted

5. Press the *MENU button* to select the *Color Balance.* submenu item.
6. The *Color Balance.* selection box will be displayed.



Figure 33. Color Balance. Select Color Selection Box

7. Use the ▲ or ▼ button to select between *Red Ch.*, *Blue Ch.* and *Green Ch.*
8. Press the *MENU button* to select the color channel to adjust



Figure 34. Set Color Balance for Selected Color Selection Box

9. Use the ▲ or ▼ button to set the desired color balance setting
10. Press the *MENU button* to confirm the change and return to the *Picture* submenu.
11. Use the ▲ or ▼ button to select the <- Back submenu item.
12. Press the *MENU button*.
13. Use the ▲ or ▼ button to select the *Exit* menu item.
14. Press the *MENU button* to exit the main menu.

Edge Enhance

1. Press the *MENU button* on the front panel of the unit. The *Output Setup* menu item will be highlighted.
2. Use the ▲ or ▼ button to highlight the *Picture* menu item.
3. Press the *MENU button* to display the *Picture* submenu. The *Contrast* submenu item will be highlighted.
4. Use the ▲ or ▼ button to highlight the *Edge Enhance* submenu item.




Figure 35. Picture Submenu with Edge Enhance. Highlighted

5. Press the *MENU button* to select the *Edge Enhance* submenu item.
6. The *Edge Enhance* selection box will be displayed.



Figure 36. Edge Enhance Selection Box

7. Use the ▲ or ▼ button to select between *User*, *Off*, *Mid* and *Max*.
8. Press the *MENU button* to confirm the change and return to the *Picture* submenu.
9. Use the ▲ or ▼ button to select the <- *Back* submenu item.
10. Press the *MENU button*.
11. Use the ▲ or ▼ button to select the *Exit* menu item.
12. Press the *MENU button* to exit the main menu.

Sharpness

1. Press the *MENU* button on the front panel of the unit. The *Output Setup* menu item will be highlighted.
2. Use the ▲ or ▼ button to highlight the *Picture* menu item.
3. Press the *MENU* button to display the *Picture* submenu. The *Contrast* submenu item will be highlighted.
4. Use the ▲ or ▼ button to highlight the *Sharpness* submenu item.




Figure 37. Picture Submenu with Sharpness Highlighted

5. Press the *MENU* button to select the *Sharpness* submenu item.
6. The *Sharpness* selection box will be displayed.



Figure 38. Sharpness Selection Box

7. Use the ▲ or ▼ button to set the sharpness level. Larger values increase the sharpness of the image.
8. Press the *MENU* button to confirm the change and return to the *Picture* submenu.
9. Use the ▲ or ▼ button to select the <- Back submenu item.
10. Press the *MENU* button.
11. Use the ▲ or ▼ button to select the *Exit* menu item.
12. Press the *MENU* button to exit the main menu.

Adjustment Menu Item

The *Adjustment* menu item provides several options to adjust the displayed picture. These are described below.

Under scan / Over scan

1. Press the *MENU button* on the front panel of the unit. The *Output Setup* menu item will be highlighted.
2. Use the ▲ or ▼ button to highlight the *Adjustment* menu item.
3. Press the *MENU button* to display the *Adjustment* submenu. The *Under/Over Scan* submenu item will be highlighted.




Figure 39. Adjustment Submenu with Under/Over Scan Highlighted

4. Press the *MENU button* to select the *Under/Over Scan* submenu item.
5. The *Under/Over Scan* selection box will be displayed.



Figure 40. Under/Over Scan Selection Box

6. Use the ▲ or ▼ button to set the amount of over scan or under scan. Negative values increase the amount of under scan. Positive values increase the amount of over scan.
7. Press the *MENU button* to confirm the change and return to the *Adjustment* submenu.
8. Use the ▲ or ▼ button to select the <- *Back* submenu item.
9. Press the *MENU button*.
10. Use the ▲ or ▼ button to select the *Exit* menu item.
11. Press the *MENU button* to exit the main menu.

Aspect Ratio

1. Press the *MENU button* on the front panel of the unit. The *Output Setup* menu item will be highlighted.
2. Use the ▲ or ▼ button to highlight the *Adjustment* menu item.
3. Press the *MENU button* to display the *Adjustment* submenu. The *Under/Over Scan* submenu item will be highlighted.
4. Use the ▲ or ▼ button to highlight the *Aspect Ratio* submenu item.




Figure 41. Adjustment Submenu with Aspect Ratio Highlighted

5. Press the *MENU button* to select the *Aspect Ratio* submenu item.
6. The *Aspect Ratio* selection box will be displayed.



Figure 42. Aspect Ratio Selection Box

7. Use the ▲ or ▼ button to select between *Source*, *16:9*, *4:3* and *Stretch*.
8. Press the *MENU button* to confirm the change and return to the *Adjustment* submenu.
9. Use the ▲ or ▼ button to select the *<- Back* submenu item.
10. Press the *MENU button*.
11. Use the ▲ or ▼ button to select the *Exit* menu item.
12. Press the *MENU button* to exit the main menu.

Horizontal Mirror

1. Press the *MENU* button on the front panel of the unit. The *Output Setup* menu item will be highlighted.
2. Use the ▲ or ▼ button to highlight the *Adjustment* menu item.
3. Press the *MENU* button to display the *Adjustment* submenu. The *Under/Over Scan* submenu item will be highlighted.
4. Use the ▲ or ▼ button to highlight the *H-Mirror* submenu item.




Figure 43. Adjustment Submenu with H-Mirror Highlighted

5. Press the *MENU* button to select the *H-Mirror* submenu item.
6. The *H-Mirror* selection box will be displayed.



Figure 44. Horizontal Mirror Selection Box

7. Use the ▲ or ▼ button to toggle between *On* and *Off*. When Horizontal Mirror is set to *On*, the picture will be flipped horizontally (about the Y-axis).



Figure 45. Horizontal Mirror for an Image

8. Press the *MENU* button to confirm the change and return to the *Adjustment* submenu.
9. Use the ▲ or ▼ button to select the <- *Back* submenu item.
10. Press the *MENU* button.
11. Use the ▲ or ▼ button to select the *Exit* menu item.
12. Press the *MENU* button to exit the main menu.

Vertical Mirror

1. Press the *MENU* button on the front panel of the unit. The *Output Setup* menu item will be highlighted.
2. Use the ▲ or ▼ button to highlight the *Adjustment* menu item.
3. Press the *MENU* button to display the *Adjustment* submenu. The *Under/Over Scan* submenu item will be highlighted.
4. Use the ▲ or ▼ button to highlight the *V-Mirror* submenu item.




Figure 46. Adjustment Submenu with V-Mirror Highlighted

5. Press the *MENU* button to select the *V-Mirror* submenu item.
6. The *V-Mirror* selection box will be displayed.



Figure 47. Vertical Mirror Selection Box

7. Use the ▲ or ▼ button to toggle between *On* and *Off*. When Vertical Mirror is set to *On*, the picture will be flipped vertically (about the X-axis).




Figure 48. Vertical Mirror for an Image

8. Press the *MENU* button to confirm the change and return to the *Adjustment* submenu.
9. Use the ▲ or ▼ button to select the <- Back submenu item.
10. Press the *MENU* button.
11. Use the ▲ or ▼ button to select the *Exit* menu item.
12. Press the *MENU* button to exit the main menu.

Horizontal Shift

1. Press the *MENU button* on the front panel of the unit. The *Output Setup* menu item will be highlighted.
2. Use the ▲ or ▼ button to highlight the *Adjustment* menu item.
3. Press the *MENU button* to display the *Adjustment* submenu. The *Under/Over Scan* submenu item will be highlighted.
4. Use the ▲ or ▼ button to highlight the *H-Shift* submenu item.




Figure 49. Adjustment Submenu with H-Shift Highlighted

5. Press the *MENU button* to select the *H-Shift* submenu item.
6. The *H-Shift* selection box will be displayed.



Figure 50. Horizontal Shift Selection Box

7. Use the ▲ or ▼ button to shift the picture left or right. Negative values move the image to the left. Positive values move the image to the right.
8. Press the *MENU button* to confirm the change and return to the *Adjustment* submenu.
9. Use the ▲ or ▼ button to select the <- *Back* submenu item.
10. Press the *MENU button*.
11. Use the ▲ or ▼ button to select the *Exit* menu item.
12. Press the *MENU button* to exit the main menu.

Vertical Shift

1. Press the *MENU button* on the front panel of the unit. The *Output Setup* menu item will be highlighted.
2. Use the ▲ or ▼ button to highlight the *Adjustment* menu item.
3. Press the *MENU button* to display the *Adjustment* submenu. The *Under/Over Scan* submenu item will be highlighted.
4. Use the ▲ or ▼ button to highlight the *V-Shift* submenu item.




Figure 51. Adjustment Submenu with V-Shift Highlighted

5. Press the *MENU button* to select the *V-Shift* submenu item.
6. The *V-Shift* selection box will be displayed.



Figure 52. Vertical Shift Selection Box

7. Use the ▲ or ▼ button to shift the picture up or down. Negative values move the image upwards. Positive values move the image downwards.
8. Press the *MENU button* to confirm the change and return to the *Adjustment* submenu.
9. Use the ▲ or ▼ button to select the <- *Back* submenu item.
10. Press the *MENU button*.
11. Use the ▲ or ▼ button to select the *Exit* menu item.
12. Press the *MENU button* to exit the main menu.

Phase

1. Press the *MENU button* on the front panel of the unit. The *Output Setup* menu item will be highlighted.
2. Use the ▲ or ▼ button to highlight the *Adjustment* menu item.
3. Press the *MENU button* to display the *Adjustment* submenu. The *Under/Over Scan* submenu item will be highlighted.
4. Use the ▲ or ▼ button to highlight the *Phase* submenu item.




Figure 53. Adjustment Submenu with Phase Highlighted

5. Press the *MENU button* to select the *Phase* submenu item.
6. The *Phase* selection box will be displayed.



Figure 54. Phase Selection Box

7. Use the ▲ or ▼ button to adjust the phase.
8. Press the *MENU button* to confirm the change and return to the *Adjustment* submenu.
9. Use the ▲ or ▼ button to select the <- *Back* submenu item.
10. Press the *MENU button*.
11. Use the ▲ or ▼ button to select the *Exit* menu item.
12. Press the *MENU button* to exit the main menu.

System Menu Item

The *System* menu item provides several options that affect the Rose Translator. These are described below.

OSD Timeout

1. Press the *MENU button* on the front panel of the unit. The *Output Setup* menu item will be highlighted.
2. Use the ▲ or ▼ button to highlight the *System* menu item.
3. Press the *MENU button* to display the *System* submenu. The *OSD Timeout* submenu item will be highlighted.




Figure 55. System Submenu with OSD Timeout Highlighted

4. Press the *MENU button* to select the *OSD Timeout* submenu item.
5. The *OSD Timeout* selection box will be displayed.



Figure 56. OSD Timeout Selection Box

6. Use the ▲ or ▼ button to set the *OSD Timeout* to *Off*, or from any time interval between 5 and 60 seconds, inclusive. The default setting is 5 seconds.
7. Press the *MENU button* to confirm the change and return to the *System* submenu.
8. Use the ▲ or ▼ button to select the <- *Back* submenu item.
9. Press the *MENU button*.
10. Use the ▲ or ▼ button to select the *Exit* menu item.
11. Press the *MENU button* to exit the main menu.

Display Notify

1. Press the *MENU button* on the front panel of the unit. The *Output Setup* menu item will be highlighted.
2. Use the ▲ or ▼ button to highlight the *System* menu item.
3. Press the *MENU button* to display the *System* submenu. The *OSD Timeout* submenu item will be highlighted.
4. Use the ▲ or ▼ button to highlight the *Display Notify* submenu item.




Figure 57. System Submenu with Display Notify Highlighted

5. Press the *MENU button* to select the *Display Notify* submenu item.
6. The *Display Notify* selection box will be displayed.



Figure 58. Display Notify Selection Box

7. Use the ▲ or ▼ button to toggle between *On* and *Off*. When *Display Notify* is set to *On*, the input / output resolution information dialog is displayed momentarily when the unit is disconnected from the source or display. The Current Resolution Display (Figure 17) shown on page 7 is displayed. In addition, the Output Resolution (page 7) also triggers the Current Resolution Display. When set to *Off*, this display is never shown.
8. Press the *MENU button* to confirm the change and return to the *System* submenu.
9. Use the ▲ or ▼ button to select the <- *Back* submenu item.
10. Press the *MENU button*.
11. Use the ▲ or ▼ button to select the *Exit* menu item.
12. Press the *MENU button* to exit the main menu.

Input Resolution Information

1. Press the *MENU button* on the front panel of the unit. The *Output Setup* menu item will be highlighted.
2. Use the ▲ or ▼ button to highlight the *System* menu item.
3. Press the *MENU button* to display the *System* submenu. The *OSD Timeout* submenu item will be highlighted.
4. Use the ▲ or ▼ button to highlight the *Input Res. Info* submenu item.




Figure 59. System Submenu with Input Res. Info Highlighted

5. Press the *MENU button* to select the *Input Res. Info* submenu item.
6. The current input resolution will be displayed in the *Input Res. Info* display box.



Figure 60. Input Res. Info Display Box

7. Press the *MENU button* to confirm the change and return to the *System* submenu.
8. Use the ▲ or ▼ button to select the <- *Back* submenu item.
9. Press the *MENU button*.
10. Use the ▲ or ▼ button to select the *Exit* menu item.
11. Press the *MENU button* to exit the main menu.

Firmware Version

1. Press the *MENU button* on the front panel of the unit. The *Output Setup* menu item will be highlighted.
2. Use the ▲ or ▼ button to highlight the *System* menu item.
3. Press the *MENU button* to display the *System* submenu. The *OSD Timeout* submenu item will be highlighted.
4. Use the ▲ or ▼ button to highlight the *F/W Version* submenu item.




Figure 61. System Submenu with F/W Version Highlighted

5. Press the *MENU button* to select the *F/W Version* submenu item.
6. The current version of firmware on the unit will be displayed in the *F/W Version* display box.



Figure 62. F/W Version Display Box

7. Press the *MENU button* to confirm the change and return to the *System* submenu.
8. Use the ▲ or ▼ button to select the <- *Back* submenu item.
9. Press the *MENU button*.
10. Use the ▲ or ▼ button to select the *Exit* menu item.
11. Press the *MENU button* to exit the main menu.

Factory Reset

1. Press the *MENU* button on the front panel of the unit. The *Output Setup* menu item will be highlighted.
2. Use the ▲ or ▼ button to highlight the *System* menu item.
3. Press the *MENU* button to display the *System* submenu. The *OSD Timeout* submenu item will be highlighted.
4. Use the ▲ or ▼ button to highlight the *Factory Reset* submenu item.



Figure 63. System Submenu with Factory Reset Highlighted

5. Press the *MENU* button to select the *Factory Reset* submenu item.
6. The *Factory Reset* selection box will be displayed.



Figure 64. Factory Reset Selection Box

7. Use the ▲ or ▼ to toggle between *No* and *Yes*.
 - a. If *Yes* is selected, then the unit will reset to factory-default settings and then automatically reboot.
 - b. If *No* is selected, then the unit will return to the *System* submenu
 - i. Use the ▲ or ▼ button to select the <- *Back* submenu item.
 - ii. Press the *MENU* button.
 - iii. Use the ▲ or ▼ button to select the *Exit* menu item.
 - iv. Press the *MENU* button to exit the main menu.

Test Patterns Menu Item

The *Test Patterns* menu item generates test patterns for the Rose Translator. The various test patterns are invoked from the submenu items. The *Test Pattern* menu item is described below.

1. Press the *MENU button* on the front panel of the unit. The *Output Setup* menu item will be highlighted.
2. Use the ▲ or ▼ button to highlight the *Test Patterns* menu item.
3. Press the *MENU button* to display the *Test Patterns* submenu. The *White* submenu item will be highlighted.




Figure 65. *Test Patterns Submenu with White Highlighted*

4. Use the ▲ or ▼ button to highlight the desired test pattern.
5. Press the *MENU button* to select the highlighted test pattern.




Figure 66. *Available Test Patterns on the Video Converter and Scaler*

6. Press the *MENU button* to return to the *Test Patterns* submenu and select a different pattern.
7. To disable the pattern and view the source image, select *Off* from the *Test Patterns* submenu.

Dip Switch Configuration

On the bottom panel of the Video Converter / Scaler is a single dip switch. Remove the piece of colored tape to reveal the dip switch bank.




Figure 67. Dip Switch on the Video Converter and .Scaler

By default, the dip switch is in the *OFF (1)* position. The dip switch should remain in this position during normal operation.



Dip Switch	Description	Position
1	Factory Reset: Toggle the dip switch from the <i>OFF (1)</i> position to the <i>ON</i> position, then back to the <i>OFF (1)</i> position	
	Normal Operation: Dip switch is in the <i>OFF (1)</i> position	

Table 1. Dip Switch Configuration

Safety

The Rose Translator, like all electronic equipment, should be used with care. To protect yourself from possible injury and to minimize the risk of damage to the Unit, read and follow these safety instructions.

Follow all instructions and warnings marked on this Unit.

Except where explained in this manual, do not attempt to service this Unit yourself.

Do not use this Unit near water.

Assure that the placement of this Unit is on a stable surface.

Provide proper ventilation and air circulation.

Keep connection cables clear of obstructions that might cause damage to them.

Use only power cords, power adapter and connection cables designed for this Unit.

Keep objects that might damage this Unit and liquids that may spill, clear from this Unit. Liquids and foreign objects might come in contact with voltage points that could create a risk of fire or electrical shock.

Do not use liquid or aerosol cleaners to clean this Unit. Always unplug this Unit from the power source before cleaning.

Remove power from the Unit and refer servicing to a qualified service center if any of the following conditions occur:

- The connection cables are damaged or frayed.
- The Unit has been exposed to any liquids.
- The Unit does not operate normally when all operating instructions have been followed.
- The Unit has been dropped or the case has been damaged.
- The Unit exhibits a distinct change in performance, indicating a need for service.

Maintenance and Repair

This Unit does not contain any internal user-serviceable parts. In the event a Unit needs repair or maintenance, you must first obtain a Return Authorization (RA) number from Rose Electronics or an authorized repair center. This Return Authorization number must appear on the outside of the shipping container.

See Limited Warranty for more information.

When returning a Unit, it should be double-packed in the original container or equivalent, insured and shipped to:

Rose Electronics
Attn: RA _____
10707 Stancliff Road
Houston, Texas 77099 USA

Technical Support

If you are experiencing problems, or need assistance in setting up, configuring or operating your Rose Translator, consult the appropriate sections of this manual. If, however, you require additional information or assistance, please contact the Rose Electronics Technical Support Department at:

Phone: (281) 933-7673
E-mail: TechSupport@rose.com
Web: www.rose.com

Technical Support hours are from: 8:00 am to 6:00 pm CST (USA), Monday through Friday.

Please report any malfunctions in the operation of this Unit or any discrepancies in this manual to the Rose Electronics Technical Support Department.

APPENDICES

Appendix A- Specifications

Part Number		Description	
CNV-VGADVISC		Rose Translator (VGA to DVI Converter/Scaler)	
Dimensions	Width (in/mm)	Depth (in/mm)	Height (in/mm)
Chassis	4.9 / 123	3.2 / 82	1 / 26
Weight		0.4 lbs (0.2kg)	
Video			
Input Interface		VGA	
Output Interface		DVI	
Maximum Input Resolution		1920 x 1200 @ 60Hz	
Maximum Output Resolution		1920 x 1200 @ 60Hz 2048 x 1080 @ 60Hz	
Maximum Pixel Clock		165 MHz	
Maximum TDMS Clock		165 MHz	
Connectors			
Video input		VGA, HD15 female	
Video output		DVI-I female (digital only)	
Firmware update		USB Mini-B	
Power		3 pin locking	
Environmental			
Operating Temp		32 to 122°F (0 to 50°C)	
Storage Temp		-4 to 185°F (-20 to 85°C)	
Relative Humidity		Max. 95% non-condensing	
Power			
Input		100 – 240VAC, 50 – 60Hz	
Output		12VDC, 1.5A	


Table 2. Rose Translator Specifications

Appendix B- Menu System Summary

This section displays the submenu systems of each menu item in the menu system.

Note: In each of the figures below, the boxes in green indicate the default setting.

Output Setup Menu



† Denotes output resolution that supports reduced blanking

⚠ Important:
 Note the following frequency information:
 23 Hz = 23.98 Hz
 29 Hz = 29.97 Hz
 59 Hz = 59.94 Hz

Figure 68. Output Setup Submenu System




Figure 69. Picture Submenu System




Figure 70. Adjustment Submenu System




Figure 71. System Submenu System

Test Patterns Menu




Figure 72. Test Patterns Submenu System

Exit Menu System



Figure 73. Exit Submenu System

Appendix C – Default Settings

Setting	Value
Aspect Ratio	Source
Brightness	50
Color Balance (Blue Channel)	50
Color Balance (Green Channel)	50
Color Balance (Red Channel)	50
Color Range	Limited
Color Temperature	Neutral
Contrast	50
Display Notifications	On
Edge Enhancement	Off
Horizontal Mirror	Off
Horizontal Shift	Off
Hue	50
OSD Timeout	5 seconds
Output Resolution	Auto-Detect
Phase	Auto
Saturation	50
Sharpness	0
Test Patterns	Off
Under/Over Scan	Off
Vertical Mirror	Off
Vertical Shift	Off

Table 3. Default Menu Settings

Appendix D- Surface Mounting Instructions

The Rose Translator can be mounted on any flat surface in the manner displayed in Figure 74 below (screws not included). There should be an inch or two of clearance between the edges of the unit and any walls or vertical surfaces to allow for sufficient clearance for the connection and disconnection of the VGA and DVI cables.

For installation on a drywall surface, use a #6 drywall screw. When installing, it is recommended to use the center hole on a stud.




Figure 74. Mounting the Rose Translator



Server Management



Solutions